

MECHANICAL TRANSPLANTER

MODEL 525 PARTS LIST

10	Inside Chain Guard	453	Pocket chain upright (after 1992)
11	32 Steel Chain for Direct Drive - 63 Links	462	11 Tooth Wheel Sprocket
12	Direct Drive Tire & Rim	521	Roll Pin
14	Outside Chain Guard	522	Clip Pin
18	Unit Chain Tightener Bracket	529	Scraper blade
19	Short Chain Tightener Pipe Bearing	530	Wheel scraper mounting bracket
22	Unit Chain Tightener Arm	533	Wheel scraper complete (after 1983)
23	Washer to Hold Spring	534	4 X 3 X 3/8 angle iron
24	Long Chain Tightener Pipe Bearing	637	Fiberglass Seat Bracket
30	Wheel Chain Tightener Pipe Bearing	639AHDD	Direct Drive Packing Wheel Hub
31	Main Frame of Rear Half	639AL	Adjustable packing wheel less hub
32	Wheel Chain Tightener Spring	649D	Diagonal shoe brace for 395R
33	Wheel Chain Tightener Arm	649DDR	Rear shoe brace for double disc
35	Lift Chain	649F	Front shoe brace for 395R
38	Wheel Hub with Sprocket	649R	Rear shoe brace for 395R
39	Main Frame of Front Half	650	Foot Rest for Models SU-3, 500, 525, 550
40	Left Clamp less U-Bolt	695	SU3 style plant box
41	32 Steel Chain for Direct Drive - 34 Links	696	Bracket
42	Right Clamp less U-Bolt	697	Bracket
43	Bushing for Clamp	715	3/8" U-Bolt for Coulters & Direct Drive
44	Chain Lift Plate	726	L Seat Bracket
48	Right Direct Drive Clamp for 4x4 or 4x7	727	1/2" U-Bolt for Seat Bracket
49	Left Direct Drive Clamp for 4x4 or 4x7	740	7/8" U-Bolt with Nuts
313	1/4 X 1-1/2" Cotter Pin	1000AL	Axle for Left Side of Model 1000
328	3/4" Flange Block	1000AR	Axle for Right Side of Model 1000
334S	Guide for pocket (disc)	R-2	Neoprene gripper for R-2 pocket
348DD	3/4" Lower Shaft for Direct Drive	24R-2	R-2 pocket for 24 pocket bed planter
362	3/4" nylon bushing w/grease zerk	1000BJD	Double disc bearing (after 1992)
373	Chain Tightener Spring	1000DDSCMP	Complete dbl.-disc w/ braces&shield
376S	Tension Spring	1000JD	13.5" Double disc shoe disc with hub (3/4" bearing)
381	7 Tooth Spacing Sprocket	1000PF	Planter frame for Model 1000
381I	7 Tooth Idler Sprocket	1000SS	Double disc shoe spacer
383	9 Tooth Spacing Sprocket	FC167	5/16 x 2" Carriage Bolt
386	Direct Drive Drawbar Shaft	FC205	3/8 x 3/4" Carriage Bolt
386P	Shaft Clip Pin	FC209	3/8 x 1" Carriage Bolt
395R-8	8"round point shoe extended 4"	FC213	3/8 x 1-1/2" Carriage Bolt
396D-24	24 hole pocket disc	FC335	1/2 x 1-1/2" Carriage Bolt
408	Dirt shield	FH227	3/8 x 3-1/4" Hex Head Cap Screw
408DD	Double disc shoe dirt shield	FH335	1/2 x 1-1/2" Hex Head Cap Screw
411	R-2 pocket spring	FMB500	7/8" Machinery Bushing
416	3/4" Oilite Bearing	FNH150	5/16" Finished Hex Nut
434	7/8" Oilite Wheel Bearing	FNH300	1/2" Finished Hex Nut
436B	L-Bolts for Pocket Guides	FW300	1/2" U.S.S. Flat Washer
		OE-74 COLB	Fiberglass Seat with Cut-out less bracket



1395 US 17 South
Elizabeth City, NC 27909
Phone:(252)264-2400

147 Hwy 32 North
Sunbury, NC 27979
Phone:(252)465-8614

5038 Old Raleigh Road
Wilson, NC 27893
Phone:(252)237-0006



www.bandsent.com



MODEL 525

